



Instructions for using external monitor with Chromebook

Chromebooks include ports that allow you to connect them to a computer monitor, television, or other display. You can mirror your desktop across multiple displays, or use the additional displays as separate desktops to gain additional screen space.

You can choose either “Mirrored” or “Extended Desktop” mode for your displays. In Mirrored mode, you have a single desktop and it’s mirrored on all your displays. In Extended Desktop mode, each display simply gives you more desktop room and they’re separate.

HOW TO USE AN EXTERNAL MONITOR



WITH THE CHROMEBOOK “OFF”, PLUG IN AN HDMI CABLE TO THE SOCKET SHOWN HERE
PLUG THE OTHER END OF THE CABLE INTO THE CORRECT SOCKET ON A MONITOR OR TV



SWITCH ON THE MONITOR AND SELECT HDMI CONNECTION AS INPUT

START THE CHROMEBOOK - IT SHOULD START UP AND THE MONITOR SCREEN SHOULD BE “BLURRY”

PRESS CTRL AND F4 KEYS AT THE SAME TIME TO SWITCH TO THE EXTERNAL MONITOR



IF IT DOES NOT SWITCH FIRST TIME, PRESS CTRL AND F4 AGAIN - USE THE CHROMEBOOK TRACKPAD TO MOVE THE MOUSE CURSOR TO THE EXTERNAL MONITOR
